



We recommend you change your cutting strip every:

6 Months

(or when the strip is worn or frayed out).

HOW TO CHANGE A CUTTING STRIP

Gouged & gunked up cutting strips will cost you vinyl. The process of changing them out can be tricky. Here's a step-by-step guide on how to change a cutting strip:

1



Use a **weeding hook**, **exacto knife** or another sharp pointed tool to pry up the existing cutting strip from one end.

2




If you have a Graphtec Cutter, use **denatured alcohol** to clean out all the adhesive residue from the previous strip left in the channel. For all Non-Graphtec Cutters, skip this step.

3



When you lay in the new cutting strip, heat it up with a **heat gun** or **hair dryer** as you **squeegee** it into the channel.

4



Trim the end of the cutting strip to fit.

The largest selection of cutting strips, cutter blades, & replacement parts at www.uscutter.com