



USCutter INSTRUCTIONS

TIPS

Print On Glossy Side

Use A 3mm Pad For Extra Pressure

Parchment Paper On Top & Bottom

RECOMMENDED PRINT SETTINGS

Printer



Laser

Media Type

"Glossy"
"Labels 2"
"Opaque"

Toner



White Toner
Compatible

Print On



Glossy Side

METAL

Clean With Alcohol

Set Press Temp To **325°F**

Open Press At **90sec**

Pressure **Heavy**

GLASS

Clean With Alcohol

Set Press Temp To **290°F**

Open Press At **60sec**

Pressure **Heavy**

CERAMIC

Set Press Temp To **350°F**

Open Press At **90sec**

Pressure **Heavy**

WOOD

Set Press Temp To **320°F**

Open Press At **50sec**

Pressure **Heavy**

ACRYLIC

Clean With Alcohol

Set Press Temp To **275°F**

Open Press At **60sec**

Pressure **Heavy**

PEELING

Peel warm or cold. For best results during a warm peel, allow substrate to sit (off heat source) for around 10 seconds before peeling.

GET IT AT: WWW.USCUTTER.COM/VERSA-SHEEN-DIGITAL-TRANSFER-PAPER